

Claw replacement Procedures

ARV20102 ARV20104 RV20103 RV20104

STEP 1: OPEN PULLING HEAD (SLEEVE)

1. Turn **CLOCKWISE** to open
2. Proceed with this instruction **ONLY** if claws are broken and needs replacement



STEP 2: PULL OUT CLAW ASSEMBLY AND REPLACE CLAW

1. Turn Claw Assembly **COUNTER-CLOCKWISE** until it can be pulled out
2. Open Claw Assembly with screwdriver and wrench as shown
3. Replace broken Claw with the new one (**#14-11** on exploded diagram*)
4. Tighten the claw assembly (reference to step2)

* Call 1-877-693-8665 or Contact us by [online form](#)



STEP 3: PUT BACK PULLING HEAD (SLEEVE)

1. Insert battery to tool. Switch tool to FORWARD. Pull Trigger to tighten Sleeve to tool
2. Examine tool by triggering tool in low speed (FORWARD and BACKWARD). Ensure it runs smooth and then test on rivets

