


ANI403 EXPLODED DIAGRAM



Item	Description	Ordering #	Q'ty
1	Housing Assembly (Incl 1A, 7, 10, 10A, 17, 18)	59930460	1
1A	Heli-Coil	59930461	3
2	Throttle Valve	59930076	1
3	O-Ring	59930071	1
4	Spring	59930072	1
5	Throttle Valve Plunger	59930077	1
6	Air Inlet	59930078	1
7	Throttle Valve Seat	59930079	1
8	Trigger	59930080	1
9	Trigger Pin	59930081	1
10	Reverse Valve Bushing	59930468	1
10A	Reverse Valve Bushing Gear	59930469	1
11	O-Ring	59930086	2
12	Reverse Valve	59930470	1
13	Steel Ball	59930087	1
14	Spring	59930088	1
15	Reverse Valve Knob	59930471	1
16	Screw	59930472	1
17	Grease Fitting	59930473	1
18	Set Screw	59930474	1
19	Rotor	59930082	1
20	Ball Bearing	59930089	1
21	Ball Bearing	59930090	1

Item	Description	Ordering #	Q'ty
22	Retainer	59930073	1
23	Cylinder	59930476	1
24	Cylinder Dowel	59930083	1
25	Rotor Blade	59930074	6
★	Rotor Blade Set (Incl 22*6pcs)	RS99I0407	1
26	Front End Plate	59930478	1
27	Rear End Plate	59930479	1
28	Gasket	59930091	1
29	Motor Clamp Washer	59930480	2
30	Hammer Frame	59930481	1
31	Hammer Pin	59930482	2
32	Washer	59930483	1
33	Hammer	59930084	2
34	Hammer Case	59930486	1
34A	Separator	59930485	1
35	Gasket	59930075	1
36	Bushing	59930487	1
37	Screw	59930488	3
38	Anvil 1/2"	59930085	1
39	Socket Retainer	59930092	1
40	O-Ring	59930093	1
★	Tune-up Kit (3,4,11*2pcs,13,14,20,21,22,25*6pcs,28,35,39,40)	RS99I0211	1